# How to add IP Camera on Blue Iris

1, My Camera IP address is 192.168.1.88.


2, Click inspect now

3, Click close

4, Click OK

5, Click OK

6, Add successful